

Gebrauchsanweisung für Hygrometer

- Die Platzierung ist sehr wichtig!
- Nicht an Außenwand oder in der Nähe der Heizung aufhängen und nicht dem direkten Sonnenlicht aussetzen.
- Alle Hygrometer, die auf dem Messprinzip der Ausdehnung einer hygroskopischen Substanz beruht, bedürfen im Interesse ihrer Anzeigen Genauigkeit einer Regenerierung. Diese besteht darin, das Hygrometer für die Dauer von ca. 1 Stunde in ein feuchtwarmes Tuch einzuwickeln. Beim Auspacken sollte die Anzeige ca. 95% sein. Ist dies nicht der Fall, sollten Sie mit einem kleinen Schraubenzieher von der Rückseite her Zeiger sogleich auf 95% einstellen. Die Regenerierung sollte Sie im Jahr etwa ein- bis zweimal wiederholen, um stets eine genaue Anzeige zu haben.

Directions for use of Hygrometers

- Healthy room climate 45 - 70% humidity relay Comfort climate
- Location important!
- Don't hang it by outside wall or near the heating.
- Preserve it from direct sunlight.
- Maintenance Regenerate the hygrometer once or twice a year if you want a good indication.
- Hygrometers are not steady!
- Regeneration: Wrap the hygrometer with warm moist temperature cloth. Past about one hour should be indication ca. 95%. Isn't it, turn pointer with Little screwdriver from the backside of hygrometer in this position.